

Android Programing

Gavrilut Dragos



- 5 methods that can be used for storage on Android based systems:
 - Shared Preferences (stores informations as a Dictionary)
 - Internal Storage (store data into device internal memory)
 - External Storage (store data into device external memory – SD-Card)
 - SQLLite DataBases
 - Via network



- Use the SharedPreferences class
- It can be obtain from an Activity in the following way:
 - Call getSharedPreferences() with the name of the preferences you need
 - Call getPreferences() if you only need one preference file for each Activity
 - Does not require any special permisions

 Values that can be written in a SharedPreferences class

Getter	Setter
getBoolean	putBoolean
getFloat	putFloat
getInt	putInt
getLong	putLong
getString	putString
getStringSet	putStringSet
getAll	

Shared Preferences - Example


```
public class MainActivity extends Activity {
   @Override
    protected void onCreate(Bundle savedInstanceState) {
        super.onCreate(savedInstanceState);
        SharedPreferences pref = getSharedPreferences("my prefs", 0);
        int someValue = pref.getInt("my value", 123);
        // use someValue
        setContentView(...);
    protected void SavePrefs() {
        SharedPreferences pref = getSharedPreferences("my prefs", 0);
        SharedPreferences.Editor edit = pref.edit();
        edit.putInt("my value", 123456);
        edit.commit();
```




Shared Preferences - Example

```
public class MainActivity extends Activity {
   @Override
    protected void onCreate(Bundle savedInstanceState) {
        super.onCreate(savedInstanceState);
        SharedPreferences pref = getPreferences(0);
        int someValue = pref.getInt("my value", 123);
        // use someValue
        setContentView(...);
    protected void SavePrefs() {
        SharedPreferences pref = getPreferences(0);
        SharedPreferences.Editor edit = pref.edit();
        edit.putInt("my value", 123456);
        edit.commit();
```

 Android has an option to create a special Activity desing for viewing and editing the preferences.





 Create a new XML file that contains every item that should be modified. The XML will be located in res\xml\my_preferences.xml


2. Create a new activity and derive it from the PreferenceActivity class

```
public class MyPrefActivity extends PreferenceActivity{
    @Override
    public void onCreate(Bundle savedInstanceState) {
        super.onCreate(savedInstanceState);
        getPreferenceManager().setSharedPreferencesName("my_prefs");
        addPreferencesFromResource(R.xml.my_preferences);
    }
}
```

3. Add the new activity in the AndroidManifest.xml

<activity android:name="com.example.studenti.MyPrefActivity" />

4. Start the Preference activity from one point in the main activity






```
<?xml version="1.0" encoding="utf-8"?>
<PreferenceScreen xmlns:android="http://schemas.android.com/apk/res/android" >
    <EditTextPreference
                                                                                ____X
                                                       5554:QVGA_480_320
        android:key="my value 2"
        android:defaultValue="123"
                                                                            🚻 📶 🕝 6:02 рм
        android:title="Some value ..."/>
                                                       SurfaceViewTest
    <CheckBoxPreference</pre>
        android:key="option 1"
                                                        Some value ...
        android:defaultValue="true"
        android:title="Option no. 1" />
</PreferenceScreen>
                                                        Option no. 1
```



```
<PreferenceScreen xmlns:android="http://schemas.android.com/apk/res/android" >
    <EditTextPreference
        android:key="my value 2"
        android:defaultValue="123"
        android:title="Some value ..."/>
                                                                                - - X
                                                       5554:QVGA 480 320
    <CheckBoxPreference
                                                                            📆 📶 🕝 6:53 рм
        android:key="option 1"
                                                       my_app
        android:defaultValue="true"
        android:title="Option no. 1" />
    <ListPreference</pre>
                                                        Some value ...
        android:key="list color"
        android:title="color list"
        android:entries="@array/color list"
                                                        Option no. 1
        android:entryValues="@array/color list results
</PreferenceScreen>
                                                        color_list
<resources>
 <string-array name="color list">
    <item>Red</item>
   <item>Green</item>
   <item>Blue</item>
    <item>White</item>
</string-array>
    <string-array name="color list results">
    <item>0</item>
   <item>1</item>
   <item>2</item>
    <item>3</item>
</string-array>
</resources>
```



```
<PreferenceScreen xmlns:android="http://schemas.android.com/apk/res/android" >
   <EditTextPreference
        android:key="my value 2"
        android:defaultValue="123"
        android:title="Some value ..."/>
   <CheckBoxPreference
        android:key="option 1"
        android:defaultValue="true"
        android:title="Option no. 1" />
   <ListPreference</pre>
        android:key="list color"
        android:title="color list"
        android:dialogTitle="Select Color"
        android:entries="@array/color list"
        android:entryValues="@array/color list results
</PreferenceScreen>
```



```
<PreferenceScreen xmlns:android="http://schemas.android.com/apk/res/android" >
   <PreferenceCategory android:title="Base options">
    <EditTextPreference
        android:key="my value 2"
        android:defaultValue="123"
                                                                                 - - X
                                                        5554:QVGA 480 320
        android:title="Some value ..."/>
                                                                             ₩ m 🛂 7:16 рм
    <CheckBoxPreference</pre>
                                                        my_app
        android:kev="option 1"
        android:defaultValue="true"
                                                        Base options
        android:title="Option no. 1" />
    <ListPreference</pre>
                                                         Some value ...
        android:key="list color"
        android:title="color list"
        android:dialogTitle="Select Color"
                                                         Option no. 1
        android:entries="@array/color list"
        android:entryValues="@array/color list results
   </PreferenceCategory>
    <PreferenceCategory android:title="Secondary optic"</pre>
                                                         color_list
    <CheckBoxPreference</pre>
        android:key="option 2"
                                                        Secondary options
        android:title="Option no. 2" />
    <CheckBoxPreference
        android:key="option 3"
                                                         Option no. 2
        android:title="Option no. 3" />
    <CheckBoxPreference
        android:key="option 4"
                                                         Option no. 3
        android:title="Option no. 4" />
   </PreferenceCategory>
</PreferenceScreen>
                                                         Option no. 4
```




```
<?xml version="1.0" encoding="utf-8"?>
<PreferenceScreen xmlns:android="http://schemas.android.com/apk/res/android" >
   <PreferenceScreen android:title="Base options" >
    <EditTextPreference
        android:key="my value 2"
                                                                                - - X
                                                        5554:QVGA 480 320
        android:defaultValue="123"
                                                                            🔛 📶 😉 7:30 рм
        android:title="Some value ..."/>
                                                       my_app
    <CheckBoxPreference
        android:key="option 1"
        android:defaultValue="true"
                                                         Base options
        android:title="Option no. 1" />
    <ListPreference</pre>
        android:key="list color"
                                                        Secondary options
        android:title="color list"
        android:dialogTitle="Select Color"
        android:entries="@array/color list"
        android:entryValues="@array/color list results
   </PreferenceScreen>
    <PreferenceScreen android:title="Secondary options"</pre>
    <CheckBoxPreference
        android:key="option 2"
        android:title="Option no. 2" />
    <CheckBoxPreference
        android:key="option 3"
        android:title="Option no. 3" />
    <CheckBoxPreference
        android:key="option 4"
        android:title="Option no. 4" />
   </PreferenceScreen>
</PreferenceScreen>
```



```
<?xml version="1.0" encoding="utf-8"?>
<PreferenceScreen xmlns:android="http://schemas.android.com/apk/res/android" >
    <EditTextPreference
        android:key="my value 2"
        android:defaultValue="123"
                                                        5554:QVGA 480 320
        android:title="Some value ..."/>
                                                                             ₩ m 🛂 8:25 рм
    <CheckBoxPreference</pre>
                                                        my_app
        android:key="option 1"
        android:defaultValue="true"
        android:title="Option no. 1" />
                                                         Some value ...
    <ListPreference</pre>
        android:key="list color"
                dialogMossage"Tost_message"
                                                         Option no. 1
        android:summary="summary"
        android.title= totor tist
        android:entries="@array/color list"
                                                         color_list
        android:entryValues="@array/color list results
                                                         summary
</PreferenceScreen>
```










```
<PreferenceScreen xmlns:android="http://schemas.android.com/apk/res/android" >
    <Preference</pre>
        android:title="Start"
        android:summary="Go to www.infoiasi.ro page" >
        <intent</pre>
            android:action="android.intent.action.VIEW"
                                                             @ 5554:QVGA_480_320
            android:data="http://www.infoiasi.ro" />
    </Preference>
                                                                                  🔛 📶 😉 9:02 рм
</PreferenceScreen>
                                                              my_app
                                                               Start
                                                               Go to www.infoiasi.ro page
```





- Represented by a location in the device internal memory
- The files saved into the internal storage can only be used by the application that saves them
- Once the application is uninstall, these files are deleted

Internal storage - Example

```
public class MainActivity extends Activity {

    protected void SaveFileToInternalStorage() {
        FileOutputStream fos;
        try {
            fos = openFileOutput("internal_file.txt", Context.MODE_PRIVATE);
            fos.write("test".getBytes());
            fos.close();
        } catch (Exception e) {
            e.printStackTrace();
        }
    }
}
```

```
/data/data/com.example.studenti/files→ internal file.xml
```

- Other functions associated with internal storage (members of the <u>Context</u> class)
 - \circ openFileInput \rightarrow opens a private file for reading
 - getFilesDir → returns the directory where the internal files are kept
 - getDir → to create/retrieve a directory
 - deleteFile → deletes an internal storage file



- SD-Card (requires WRITE_EXTERNAL_STORAGE permisions)
- Obtaind using: getExternalStorageDirectory, getExternalStoragePublicDirectory,
- getExternalStoragePublicDirectory can be used to obtain the location of some specials directoris such as:
 - Music
 - Podcasts
 - Ringtones
 - Alarms
 - Notifications
 - Pictures
 - Movies
 - Downloads

SQLLite databases

```
public class MainActivity extends Activity {
    private SQLiteDatabase myDB;
   @Override
    protected void onCreate(Bundle savedInstanceState) {
        super.onCreate(savedInstanceState);
        setContentView(...);
        OpenDB();
    public void OpenDB() {
        SQLiteOpenHelper sql = new SQLiteOpenHelper(this, "my_db", null, 1) {
            @Override
            public void onUpgrade(SQLiteDatabase db, int oldVersion, int newVersion) {
            @Override
            public void onCreate(SQLiteDatabase db) {
         };
         myDB = sql.getWritableDatabase();
         myDB.execSQL("CREATE TABLE names (name TEXT)");
```



/data/data/com.example.surfaceviewtest/databases →my_db